



Intelligent disinfection & sterilization
Atomization device

- Rechargeable Electric Ultra-low capacity -

Space Atomizing Sterilizer
ZL-KX10



IMMUNITY

SOCIAL SAFETY

Electrostatic Sprayer

USER'S MANUAL



I. PRODUCT STRUCTURE DIAGRAM

This product is a new type of lithium battery ultra-low-capacity sprayer.

Speed brushless fan, high-capacity lithium battery, water pump, LCD screen, cleaning Reflux system, power switch and other components.

This machine is multi-functional and multi-scenario use. According to different application scenarios.

Users can choose corresponding accessories by themselves.



II. PRODUCT FEATURES

1. Wide range of uses: mainly suitable for spraying anti-virus disinfectant solutions.

Airports, stations, large shopping malls, supermarkets, hotels, hotels, restaurants, entertainment Disinfection of places, garbage stations, schools, military camps, subways, ships, residential small Districts, parking lots, food factories, warehouses, prisons, post-disaster disinfection and animal husbandry Farming disinfection and other fields.



2. The product is small in size, light in weight, flexible and convenient to carry.
3. Unique intelligent spray management system.

III. INSTRUCTIONS FOR USE

- A. Open the packing box, take out the product and place it horizontally, add a small amount of water in it, (1/2 liter)
- B. Clean water must pass through the filter to prevent impurities from clogging the nozzle.
- C. Turn on the power switch to make it spray, and ensure nozzles are dispensing, and then
- D. Turn on the switch on the air gun to see if the air gun is operating normally.
- E. Remove all water from tank, and fill with micro sure surface disinfectant.

IV. SAFETY PRECAUTIONS

- A. In order to ensure the safety of yourself and others, please read carefully and understand and follow Protective measures.
- B. **You must wear protective glasses, masks, Rubber gloves and anti-penetration of chemicals during operation Outer clothing, so as to avoid skin damage caused by chemicals.**
- C. It is strictly forbidden to use sprayers on people and animals during use. Food etc. spray.
- D. It is strictly forbidden to remove the air gun cover during operation, and it is strictly forbidden to run the fan at high-speed Touch the fan blades with your hands and objects.
- E. Smoking and eating are prohibited during spray operation.



- F. It is strictly forbidden to operate and use by women and children sick or breastfeeding during pregnancy.
- G. Cut off each power supply first when repairing.

V. MATTERS NEEDING ATTENTION

1. Do not plug into the power socket with wet hands when charging.
2. Use the filter when adding water.
3. It is strictly forbidden to disassemble the machine by yourself! If you need to disassemble, please contact the manufacturer / supplier. Service personnel.
4. Please charge in time after each operation, the charging time is about 90 mins (might need longer).

VI. MAINTENANCE

1. After each use, add a small amount of water, turn on the switch to clean the bucket Residual medicine in the body and the residual liquid in the pipeline system to avoid corrosion and blockage the piping system such as the sprinkler, and wipe the body dry.
2. It is forbidden to use powder, insoluble powder and corrosive liquid.
3. After maintenance, the machine should be placed in a ventilated and dry place, away from fire and sunlight.
4. When the machine is not used for a long time, it is recommended to charge the battery once every two months. Prevent power loss.

VII. COMMON PROBLEMS ANALYSIS SOLUTION

1. The connecting wire is broken, replace it or weld it again.
2. The power switch is damaged, replace the switch.
3. The fan is damaged, replace the fan.
4. The nozzle does not atomize
5. Unscrew the nozzle (be careful not to lose the spring and other parts), clean it with clean water and re Install correctly.



6. Water leaks at the nozzle, the O-ring is damaged or the nozzle is not tightened, replace the O-type pad and tighten it.

VIII. AFTER SALES SERVICE

This product cannot be used normally if there is a failure during the guarantee period.

With our company the after-sales technicians can return to the factory for repairs after identification (for related questions, please call the company's technicians (Guide can solve it by yourself)

Pot body, charger, fan, water pump, LCD screen, non-human damage year.

Other accessories are guaranteed for 8 months.

IX. EQUIPMENT PARAMETERS

Battery	Core lithium battery
Sprayer body	ABS material
Tank capacity	10L(2.27Gallons)
Working times	3.5 hours
Charging time	90Minutes
Nozzles size	10-50 μ m
Effective range	3-6m (Electrostatic with fan open) 1-2m (Electrostatic with fan off)
Rated Voltage	24V
Battery capacity	20AH
Net Weight	7.8kg
Gross Weight	11.5kg
Packing size	740*280*670mm
Warranty	12 months





Sourced Trough



Company Details

- SIMPLY SHAMAZEN Ltd.
- T/A: www.medcareppe.com
- Company No.: 66888
- VAT No.: IE3684619UH

Contact

- +353 89 600 7637
- hello@medcareppe.com

Follow Us



Registered Address

- Moate House
- Ratoath
- Main street
- County Meath
- A85 YK13

Designed & Co-Developed By



Powered By



SIMPLY SHAMAZEN LTD



Legal ↓



Certificate of conformity

Product number:

Date of manufacture:

Inspectors:

This product is approved to leave the factory after inspection!



Intelligent disinfection and sterilization atomization device

(Rechargeable electric ultra-low capacity)

Space atomizing sterilizer

-*Warranty Card* -

Purchase model:

Contact number:

Purchase date:

Buyers' phone:

address:

This product cannot be used normally if there is a failure during the guarantee period. To our after-sales technical staff

Return to the factory for repairs after identification (relevant problems should be solved by the telephone guidance department of the company's technical staff)

The company's products are guaranteed for one year (except for man-made damage)
